



Do It Yourself

DO IT YOURSELF DO IT YOURSELF DO IT YOURSELF DO IT YOURSELF DO IT YOURSELF DO IT Y



Topseal Cleaning Procedures

- 1 Hose off all paving or cement generously, making sure to wet down the surface completely.
- 2 Apply a chemical mix depending on how dirty the bricks are, making sure not to miss any areas at all.
- 3 Broom in chemical mix into areas with heavy staining or markings.
- 4 High pressure clean all paving, repeat chemical mix on areas that are still marked if needed. Making sure to pressure clean it off immediately.
- 5 Allow no traffic on cleaned area and wait until completely dry before applying sealer.

For any further cleaning information please contact us on 9359 0513.

Topseal applied with roller & non-slip application

- 1 The substrate must be completely clean and dry before proceeding. Marks on surface will show through.
- 2 Do not overfill roller and roll excess from edges of roller to prevent lines of thicker product. Apply a consistent thickness.
- 3 For first coat, apply in small sections rolling in a north/ south direction.
- 4 Second coat may be applied as soon as first coat is dry (approximately 1 hour depending on weather conditions).
- 5 For second coat, apply in small sections rolling in an east/ west direction.
- 6 Depending on weather conditions the Topseal will be dry enough to take light foot traffic and rain after 4 hours.
- 7 Do not allow wheeled traffic or storage of any materials on Topseal for 3-4 days, depending on weather conditions.

To achieve a non slip finish with Topseal sealer a light sprinkling of fine washed white quartz sand is applied while the first coat is still damp - second coat is applied over first coat to lock in sand.

Please note Process can be achieved by using an airless spray gun, with the same procedures applied.



www.topseal.com.au

